

CHANGING CANNULAS

Bleach do crystallise easily. Depending on its quality, the cannula injecting bleach will be blocked within 3 months. We need to avoid it. Once it is obstructed the pool will not be treated, your regulator EX 2012 will warn you showing:

“O.R.P TIMEOUT”

Cannulas that need to be cleaned every 3 months

To avoid reaching wear of the springs located into the cannulas and risk a products siphoning it is recommended to replace cannulas every two years.

Nut maintaining the tube (unique element to unscrew)

Cannula (element to change)

Cannula Foot (allow sealing with your filtering) do not unscrew at all.

First close the valves to get your filtering isolated

Unscrew the top nut connecting the tube with the cannula. Take really care to grab properly the two other parts to avoid them rounding. In fact the cannula foot ensures the sealing of your installation.

It is better to do this operation:

- Filtering off
- Equipped with rubber gloves.
- With old clothes.

Unscrew the cannula and take out the old joint. Replace by a new cannula, taking care not to forget the new joint. (all screws are only done by hand) Replace the tube. Do the same way with the other cannula.

Arrow engraved to indicate products direction.